



© 1999 Drawings remain the property of Vental Australia Pty. Ltd.



V80 GUIDE DETAIL - PLAN VIEW

Dwg. No. V10201

Single & double guide rails, standoffs and louver slats shown in plan view. Standoffs are telescopic fixing used to attach guide rails to window mullions or other non-moving structure (additional standoff details in dwg. no. V10202). Single guide rails may be used without standoffs by side fixing directly through the guide rail into the window reveal or other non-moving structure.